

Fitting Kits for 1191 and 1190FP In-Out Heads and Clack 1" and 1.25" Control Valves

1" PVC Male NPT Elbow Assembly



Order No. V3007

3/4" x 1" PVC Solvent Elbow Assembly



Order No. V3007-01

1" Brass Sweat Assembly LF



Order No. V3007-02LF

3/4" Brass Sweat Assembly LF



Order No. V3007-03LF

1" Plastic Male NPT Assembly



Order No. V3007-04

1.25" Plastic Male NPT Assembly



Order No. V3007-05

Fitting Kits for 1191 and 1190FP In-Out Heads and Clack 1" and 1.25" Control Valves

1" Plastic Male BSPT Assembly



Order No. V3007-06

1.25" & 1.5" PVC Solvent Assembly



Order No. V3007-07

1.25" Plastic Male BSPT Assembly



Order No. V3007-08

1.25" & 1.5" Brass Sweat Assembly LF



Order No. V3007-09LF

3/4" SharkBite® Assembly



Order No. V3007-12

1" SharkBite® Assembly



Order No. V3007-13

3/4" Plastic Male BSPT Assembly



Order No. V3007-14

3/4" John Guest QC Elbow Assembly



Order No. V3007-15

Vertical 90° Adapter Kit



Order No. V3191-01